

Processing Chart for Silver Gelatin Prints

Paper: Bergger VCCB - Variable Contrast Warmtone
 Developer: Ansco 130 - or Photo Formulary 130
 Fix: TF-4 Alkaline Fix - Photo Formulary
 All temps as close to 68 degrees F as possible

TRAY 1	WATER (to be used as contrast lowering bath or to develop highlights if needed.)
TRAY 2	ANSCO 130 / WATER 1:1 (Min 3 minutes - Max 8-10 minutes)
TRAY 3	WATER STOP (Preferably running water) (45 sec.)
TRAY 4	TF-4 FIX / WATER 1:3 (3 mins)
WASH 20 MINUTES	
DRY	
BLEACH IF NEEDED (1/2 tsp. of Potassium Ferricyanide to a 12 oz. jar of water)	
TRAY 5	WATER
TRAY 6	2nd FIX SODIUM THIOSULFATE 16oz to 1/2 GALLON WATER (3 mins)
TRAY 7	SELENIUM TONING TONER / WATER 1:30 (6.5 mins)
TRAY 8	HYPO CLEARING AGENT / PERMA WASH 3oz PW to 1 gallon of WATER (5 mins)
TRAY 9	RINSE
WASH IN ARCHIVAL WASHER LOW WATER FLOW RATE (45 mins)	
DRY, SPOT, MOUNT	